
INSTALLATION INSTRUCTIONS

FORTIS REAR BUMPER 2019 RAM 1500

PARTS LIST:

1	Fortis Rear Bumper Assembly	8	12mm x 37mm x 3mm Flat Washers
2	Plastic Plugs for license plate mount	4	12mm Nylon Lock Nuts
6	Retaining Clips	14	4mm x 10mm Button Head Bolts
6	15.5mm x 25mm x 2mm Foam Washers	4	4mm x 12mm x 1.0mm Flat Washers
6	20mm x 2mm Foam Washers	2	4mm Lock Washers
6	Sensor Hole Plugs	2	4mm Hex Nuts
1	Sensor Cover Kit	1	2.5mm Wrench
4	12-1.75mm x 35mm Hex Bolts		



PROCEDURE:

REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION. BUMPER IS HEAVY, ASSISTANCE IS HIGHLY RECOMMENDED TO AVOID POSSIBLE INJURY OR DAMAGE TO THE VEHICLE. ALLOW EXHAUST TO COMPLETELY COOL BEFORE STARTING INSTALLATION.

- 1. Start installation by unplugging the wiring harness leading to the rear bumper, (Figure 1). Move harness away from the bumper.
- 2. Remove the license plate. Remove the (2) hex bolts behind rear license plate, (Figure 2).
- 3. Place blocks or jack stands under the bumper to support it during bumper bolt removal. Once the bumper has been safely supported, remove the (4) factory hex nuts, (2 per side), and slide the rear bumper off of the end of the frame, (Figures 3 & 4). WARNING! Assistance is required to hold the bumper in place during hardware removal and to prevent the bumper from falling. Move the bumper to a clean stable work surface.
- 4. Unplug and remove the wiring harness from the factory bumper, (Figure 5). Remove the license plate lights, towing harness plug, parking sensors and tire pressure monitoring sensor (TPMS) from the back of the bumper as equipped.
- 5. Determine if the vehicle is equipped with bumper mounted parking sensors. **NOTE**: Depending on tow package, it may be necessary or easier to install all sensors, (if equipped), or plugs before installing the Bumper.

Models without bumper sensors:

- a. Select the included (6) Rubber Plugs, (Figure 6).
- **b.** From behind bumper, push plugs into sensor mounting holes, **(Figure 6)**. 4mm Screws have been provided to lock the plugs in the sleeve. Use is optional.

Models with parking sensors:

a. Remove the silicone seal from the end of the sensor. Slide the included larger Sensor Seal over front of sensor, (Figure 7).


- b. Insert sensor with Seal into sensor mount, (Figure 8).
- c. Place Foam Washer over end of sensor. Push Sensor Retaining Clip into sensor mount and lock into mounting holes, (Figure 8).
- d. Repeat previous Steps to install remaining parking sensors.
- e. Install wiring harness for sensors. **IMPORTANT**: Run the wiring harness above the Brackets to clear the exhaust tips. It may be necessary to remove a portion of the outer wiring cover on the harness to allow the harness to reach the sensors.
- f. Optional: Secure each sensor to the socket with (2) 4mm x 10mm Button Head Screws, (Figure 6). IMPORTANT: Sensors fit snug in sockets. The 4mm Screws are used to apply slight pressure to lock the sensors in place. Tighten both screws evenly until they touch the sensor body only. Do not overtighten screws or damage to sensors will result.


Models with TPMS (tire pressure monitoring system).

- **a.** Remove the sensor from the back of the bumper, **(Figure 9)**. **NOTE**: It may be necessary to partially disassemble the plastic bumper panel to remove the sensor.
- b. Attach the sensor to tabs on back of bumper with included (2) 4mm Button Head Screws,
 (4) 4mm Flat Washers, (2) 4mm Lock Washers and (2) 4mm Hex Nuts, (Figures 10 & 11).
 Do Not Overtighten 4mm hardware or damage to sensor could result.
- c. Once installed, plug wiring harness into TPMS sensor.
- 6. Select the driver/left factory license plate light, (Figure 12). Insert the light into the hole in the driver/left side of the Bumper. Reuse the factory hex bolt to attach the light to mounting tab on the back of the Bumper, (Figure 13). Repeat this Step to install the passenger/right license plate light.
- 7. With assistance, position the Bumper up to the bumper brackets on the ends of the frame. Temporarily support the weight of the Bumper Assembly. **WARNING**: To avoid possible injury or damage to the vehicle, do not proceed until the Bumper is fully and safely supported.
- Line up the (2) mounting holes in the back of the driver side of the bumper with the brackets on the end of the frame. Attach the Bumper to the frame with the included (2) 12mm Hex Bolts, (4) 12mm Flat Washers and (2) 12mm Nylon Lock Nuts, (Figures 14 & 15). Leave hardware loose at this time. Repeat to attach the passenger/right side of the Bumper.
- **9.** Slowly open the tail gate and check for clearance. Level and adjust the Bumper and tighten all hardware.
- **10.**Locate the mounting slots in the tabs on the back of the Bumper to install lights if desired. **NOTE:** Lights not included.
- 11. Insert the trailer plug into the opening in the Bumper if equipped, (Figure 16). Insert the included (2) push-in plugs to attach the license plate to the Bumper, (Figure 16). Reuse factory hardware to attach license plate to plastic plugs in Bumper.
- 12. Reattach the bumper wiring harness to the main wiring harness.
- **13.** Do periodic inspections to the installation to make sure that all hardware is secure and tight.

To protect your investment, Do not use any type of polish or wax that may contain abrasives that could damage the finish. Mild soap may be used to clean the Bumper assembly.

Driver/left side installation pictured





(Fig 2) Remove license plate to access and remove (2) hex bolts (arrows)




(Fig 3) Remove hex nuts to remove bumper (arrow)

WARNING! Do not remove bumper bolts unless the bumper is properly supported on blocks or stands or the bumper may fall.


Models with dual exhaust, allow exhaust to completely cool before starting installation




Driver/left side installation pictured




(Fig 5) Remove license plate lights, remote antenna (Fig 10), parking sensors and wiring harness




WARNING! Do not crawl under bumper unless the bumper is properly supported on blocks or stands or the bumper may fall.



(Fig 6) Push Rubber Plug into sensor mounting sleeve. Use 4mm Screws to lock plugs in place.



Driver/left side installation pictured



Driver/left side installation pictured

