



1-800-366-9712

INSTALLATION INSTRUCTIONS

IMPORTANT NOTICE: Be sure to inspect and test fit product before having it coated or painted. Ranch Hand will not be responsible for the cost of the coating if any problems with fit or finish are not noted and addressed beforehand.

**2015-19 GMC 2500HD/3500HD GRILL GUARD
PART# GGG151BL1 / GGG151BLS**

NOTE: Work on one side at a time so the bumper does not move while installing.

1. Start with the driver side. Remove the side and bottom tow hook bolts.
2. Remove the tow hook. Slide the formed side of the mounting bracket through the tow hook opening from the back side. The mounting bracket will be installed to the outside of the frame. Reinstall the tow hook to its original position. Make sure the bolt goes through the lower mounting bracket, frame, and tow hook. Use the 2 factory bolts to mount the mounting bracket to the frame per side.
3. Follow the same steps for the passenger side using.
4. Open the hood and remove the plastic radiator cover. There will be (12) plastic clips.
5. Remove the (4) 10 mm bolts holding the grille in place. Carefully pry grille away from its position (10) snap clips.
6. Remove the top 2 inner 15 mm bumper bolts. Do one side at a time. Mount the top bumper bracket over the hole and reinstall the bumper bolt. Mount the spacer and top mounting bracket to the bumper bracket. The top bracket will angle outward to the side of the vehicle. Do the same for the other side.
7. Mount the grille guard to the bottom and top brackets. Use the ½” carriage bolts to install. *If the brackets are a little wide, you can push them in when you get ready to slide the grille guard over the brackets.* Level the grille guard and then tighten carriage bolts.
8. Tighten all the bolts and then reinstall the grille and plastic radiator cover.

MAKE SURE ALL NUTS AND BOLTS ARE TIGHT!

----- **WARNING** -----

Special care should be exercised in the handling, storage and installation of Ranch Hand equipment.

The actual weight of each piece of equipment will vary depending on style and model. The weight of the equipment is sufficient in volume to warrant special care, assistance and in some instances, the use of mechanical equipment during the transfer and installation of the equipment. Do not assume a position directly under the equipment during installation. Be sure the equipment has been connected and stabilized during installation to prevent falling or shifting of positions.

Periodically check tightness of bolts to make sure they are tight, and unlikely to fail.

Rev. 2021