

1992-1996 FORD, F150-F350, BRONCO

INSTALLATION INSTRUCTIONS



SAFETY

Know safety, no injury. Know injury, no safety. ~Author Unknown

If there are any questions, call 1-855-HHTOUGH

- **READ ALL SAFETY INSTRUCTIONS BEFORE INSTALLATION**
 - FOLLOW ALL INSTRUCTIONS FOR PROPER ASSEMBLY
 - WEAR APPROPRIATE EYE PROTECTION
 - EXERCISE CARE WHEN LIFTING COMPONENTS
 - USE APPROPRIATE TORQUE FOR BOLTS

SUGGESTED TORQUE VALUES FOR STEEL GRADE SAE 5 BOLTS

BOLT DIAMETER (INCH)	TREADS PER INCH	TORQUE (POUND-FEET)
1/4	20	7
5/16	18	14
3/8	16	25
7/16	14	40
1/2	13	60
9/16	12	88
5/8	11	120
3/4	10	200
7/8	9	302
1	8	466

California Proposition 65



WARNING


Cancer and Reproductive Harm

www.P65Warnings.ca.gov

DO NOT PAINT OVER THIS LABEL. REPLACE IF DAMAGED OR LOST

DKB150_00

I. PARTS LIST



ITEM NO.	QTY.	PART NUMBER	DESCRIPTION
1	1	601-56-2958	RIGHT BAR MOUNT
2	1	601-56-2959	LEFT BAR MOUNT
3	1	60K-56-0057	HARDWARE KIT #57
4	1	60P-56-0913	600-56-0913 POLISHED

II. TOOL LIST


1. Basic tool set
2. Blue masking tape
3. 21mm socket
4. 7/16" socket
5. 7/16" wrench

III. REMOVAL OF BUMPER

1. Disconnect battery.
2. Using blue masking tape, mask along the profile of your truck above the bumper. This will help protect your truck from accidental scratches.
3. Using 21mm socket, remove four nuts attaching bumper to frame. Remove bumper and set aside. The bolts are accessed from behind the bumper.

IV. INSTALLATION OF HAMMERHEAD BUMPER

1. Install all lights and sensors in Hammerhead bumper at this time. Use included Bar mount brackets (601-56-2958 and 2959) and Hardware kit #57 to attach 20" bar in bumper to mount in bumper. Use hole in bracket and bumper that works best with your light bar. Tighten bolts from hardware kit #57 with 7/16" socket and wrench.



2958-2959 brackets



2. Layout OE bolt strips and nuts.
3. Using a hoist or a few friends, attach bumper to frame mounts using OE hardware. Start all nuts before aligning bumper. Align bumper a minimum of 1/4" below headlights. When truck flexes off-road, this distance allows your bumper and body to have clearance. Tighten bolts with 21mm socket.



Congratulations! Your product installation is now complete. Thank you for your purchase.