INSTALLATION SEQUENCE HAS CHANGED.

READ ENTIRE INSTRUCTION MANUAL PRIOR TO INSTALLATION!!!



Product Number: A4150, A4151, A4152

A4250, A4251, A4252

Application: 2017-2019 F250-F350

SAFETY

Your safety and the safety of others is very important.

- In order to help you make informed decisions about safety, we have provided installation instructions and other information.
- These instructions alert you to potential hazards that could hurt you or others.
- Please do a job safety analysis (JSA) before each task to identify potential hazards for your situation and remove/protect against them.
- You must use your own good judgment, and take your time.

Read and understand all safety precautions and instructions before installing this product.

THIS PRODUCT IS FOR OFFROAD USE ONLY. ALL LIABILITY FOR INSTALLATION AND USE RESTS WITH THE OWNER.

CARELESS INSTALLATION AND OPERATION CAN RESULT IN SERIOUS INJURY OR EQUIPMENT DAMAGE.

SENSORS FIELD OF VIEW WILL BE ALTERED WITH USE OF THE REPLACEMENT BUMPER.

Injury hazard Failure to observe these instructions could lead to severe injury or death. ■ Always remove jewelry and wear eye protection. Always use extreme caution when jacking up a vehicle for work. Set emergency brake and use tire blocks. Locate and use the vehicle manufacturers designated lifting points. Use jack stands. Always use appropriate and adequate care in lifting components into place. ☐ Always insure components will remain secure during installation and operation. Always wear safety glasses when installing this kit. A drilling operation will cause flying metal chips. Flying chips can cause serious eye injury. Always use extreme caution when drilling on a vehicle. Thoroughly inspect the area to be drilled (on both sides of material) prior to drilling, and relocate any objects that may be damaged. Always use extreme caution when cutting and trimming during fitting. Always tighten all nuts and bolts securely per installation instructions. Always route electrical cables carefully. Avoid moving parts, components that become hot and rough or sharp edges. Always insulate and protect all exposed wiring and electrical terminals.





Product Number: A4150, A4151, A4152

A4250, A4251, A4252

Application: 2017-2019 F250-F350

☐ Always perform regular inspections and maintenance on mounts and related hardware.

I. Overview

Congratulations on your purchase of the industries' best and most stylish Ford Super Duty Winch Bumper! This bumper has been **engineered** for strength while keeping the weight down. It can accept the Warn 16.5 winch... and look cool doing it.

This product has also been **engineered** to allow alignment in three directions so you will end up with a very professional fit.

Your bumper was designed in 3-D, fabricated, and powder coated... all in the U.S.A.

Enjoy the fit and finish of a quality Ford Super Duty Winch Bumper from Fab Fours Inc!





Product Number: A4150, A4151, A4152

A4250, A4251, A4252

Application: 2017-2019 F250-F350



II. Vehicle Preparation

1. Start by removing four bolts around tow hook on each side of vehicle. This will require an 18mm socket.







Product Number: A4150, A4151, A4152

A4250, A4251, A4252

Application: 2017-2019 F250-F350



2. Next, with the help of someone holding the bumper in place, remove the four 15mm bolts from the bumper supports on both sides of vehicle.







Product Number: A4150, A4151, A4152


A4250, A4251, A4252

Application: 2017-2019 F250-F350

3. The bumper can now be removed. (Be careful when removing bumper if vehicle has a block heater, as this will have to be unplugged during this step.)

4. With the bumper off the vehicle, you can now remove the tow hooks by removing the four 18mm bolts

located under the top of frame rail.



5. Next, using 18mm socket remove the two nuts on either side of the frame attaching frame horns to frame. Set bolt strips and nuts aside as they will be used in the installation of Fab Fours bumper. (See image.)





Product Number: A4150, A4151, A4152

A4250, A4251, A4252

Application: 2017-2019 F250-F350







Product Number: A4150, A4151, A4152

A4250, A4251, A4252


Application: 2017-2019 F250-F350

III. BUMPER INSTALLATION

Optional: If installing winch and roller fairlead into bumper, do it at this time. Follow the winch manufacturer's instructions for installation. If you are installing a winch with a pulling capacity of 16,000 lbs., the front face mounting holes must be used.

If not installing a winch, a license plate may be installed onto the front face of the bumper. (Hardware not included.)

1. Start by installing Fab Fours mounting bracket as shown below. Do not fully tighten the hardware.







Product Number: A4150, A4151, A4152

A4250, A4251, A4252

Application: 2017-2019 F250-F350



- 2. Once the brackets are loosely installed, with the help of two other people, lift the bumper into place.
- 3. With the bumper in place loosely install bolt strips and hardware.
- 4. Next hold the bumper into desired position on the truck. NOTE: Fab Fours recommends a MINIMUM gap of 3/8" at the outer fenders and headlights to prevent paint damage in normal operation.
- 5. With bumper in position you can begin tightening all hardware. Tighten all fasteners fully; beginning with frame mounts. Then tighten all mount-to-bumper fasteners.





Product Number: A4150, A4151, A4152

A4250, A4251, A4252

Application: 2017-2019 F250-F350

IV. Maintenance/Care

☐ Periodically check and tighten all fasteners.


☐ Stripped, fractured, or bent bolts or nuts need to be replaced.

☐ Keep all surfaces free of dirt, road grime, and standing water to ensure finish longevity.

V. Contact Information

Fab Fours Inc. Phone (866)-385-1905 2213 Industrial Park Rd. Fax (866)-574-1424

Lancaster, SC 29720 Email Support@fabfours.com



More than expected... Better than expected

