

#### 23+/FORD BRONCO RAPTOR

#### **BOMBER FRONT BUMPER**



#### **PREPARATION**

We recommend reading through the installation instructions in whole before performing the work.

- · Disconnect the negative battery terminal. Park the vehicle on level ground and set the emergency brake.
- When button head bolts are being used, install the supplied washer on the nut side. Then, hold the bolt stationary and
  only turn the nut to tighten. Do not turn the bolt to tighten hardware assembly, unless otherwise noted.
- Anti-seize is recommended for all fasteners.



\*\*This installation requires 2 people for best results\*\*



- 6- Hex Head Bolt (3/8-16 x 1 1/4")
- 6- Fender Washers (3/8")
- 4- Sensor Plugs



- 2 hours for OEM Removal/Bumper Install
-1.5 Additional Hour to Wire Cube Lights/Winch

\*\*Labor Rates are based on a vehicle with no pre-existing damage. Wiring labor is based on a standard wiring procedure with light switches installed in an easily accessible location. Custom light triggering or switch mounting location will result in a greater labor charge.\*\*



(Sockets) 9/16, 10mm, 15mm
(Box end wrenches) 9/16, 10mm, 15mm
(Torx) T30, T40
Fastener remover or flathead screwdriver
Zip ties
Ratchet



BOMBER FRONT BUMPER 23+/FORD BRONCO RAPTOR

## **OPTIONS**

## **BAJA OPTION**



## **RIGID OPTION**





BOMBER FRONT BUMPER 23+/FORD BRONCO RAPTOR

**REMOVAL** 

☐ STEP 1

Disconnect the wire harness plug located on the driver side.





#### **BOMBER FRONT BUMPER**

23+/FORD BRONCO RAPTOR

### **REMOVAL**

STEP 2

Remove the skid plate using a (15mm socket). \*\*Keep these for they will be used later on in the install\*\*



Page 4 | Addictive Desert Designs




## BOMBER FRONT BUMPER 23+/FORD BRONCO RAPTOR

**REMOVAL** 

STEP 3

Remove all the push pins for the front cover using a (fastener remover/flathead).



Page 5 | Addictive Desert Designs



#### **BOMBER FRONT BUMPER**

23+/FORD BRONCO RAPTOR

### **REMOVAL**

STEP 4

Remove the mounting bolts located on the tow hooks using a (15mm socket). You can now remove the bumper.





#### **BOMBER FRONT BUMPER**

23+/FORD BRONCO RAPTOR

### **REMOVAL**



STEP 5

Follow the ACC install guide before continuing with the install.

https://cdn.shopify.com/s/files/1/0627/4508/4140/files/2021-ford-bronco-cruise-control-install. pdf?v=1654182892





#### BOMBER FRONT BUMPER

23+/FORD BRONCO RAPTOR

## **REMOVAL**



STEP 6

Remove the mounting bracket plastic nuts located behind the frame horns. There are 2x on each side.



Page 8 | Addictive Desert Designs




#### BOMBER FRONT BUMPER

23+/FORD BRONCO RAPTOR

### **REMOVAL**



Remove the plastic covers on each outer sides using a (fastener remover/flathead).





#### **BOMBER FRONT BUMPER**


23+/FORD BRONCO RAPTOR

### **REMOVAL**



STEP 8

Next, Remove the 4x bolts holding the light brackets using a (T30). Then disconnect the plug located above the lights.








#### **BOMBER FRONT BUMPER**

23+/FORD BRONCO RAPTOR

**REMOVAL** 



Remove the tow hook brackets using a (10mm socket).





#### **BOMBER FRONT BUMPER**


23+/FORD BRONCO RAPTOR

**REMOVAL** 



STEP 10

Remove the 5x bolts holding the middle plate using a (T40).





#### **BOMBER FRONT BUMPER**

23+/FORD BRONCO RAPTOR

## **REMOVAL**



Remove all of the front and top face bolts that are indicated below using a (T40).





#### **BOMBER FRONT BUMPER**

23+/FORD BRONCO RAPTOR


### **REMOVAL**



**STEP 12** 

You can now remove the wire harness by removing the sensors and sensor bezels by follow the images below. \*\*Remember the orientation for this will be important in step 13\*\*

SPREAD THE TABS ON EACH SIDE
OF THE SENSOR TO RELEASE IT AND
PULL OUT





SQUEEZE TOGETHER ON THE INSIDE OF THE BUMPER THEN PUSH OUT





#### **BOMBER FRONT BUMPER**


23+/FORD BRONCO RAPTOR


### **INSTALLATION**




Install the sensor bezels into the ADD bumper. Ensure they are in the same orientation as OEM.

\*\*If the bezels do not click into place you may have to trim the tabs to match the thickness of the bumper as shown below\*\*










## BOMBER FRONT BUMPER 23+/FORD BRONCO RAPTOR

## **INSTALLATION**



Install the U-nut clips in the provided mounting slots.





#### **BOMBER FRONT BUMPER**

23+/FORD BRONCO RAPTOR

#### **INSTALLATION**

STEP 15

Install the wiring harness along the top of the bumper. Unplug the outer sensors to pass through the back side of the mounting plate.







#### **BOMBER FRONT BUMPER**

23+/FORD BRONCO RAPTOR

### **INSTALLATION**



STEP 16

You can now install the bumper with the 6x provided 3/8" hex head bolts, and washers using a (9/16 socket/wrench).






#### **BOMBER FRONT BUMPER**

23+/FORD BRONCO RAPTOR

### **INSTALLATION**



Install the skid plate using the same mounting holes with the same OEM hardware using a (15mm socket).







#### BOMBER FRONT BUMPER

23+/FORD BRONCO RAPTOR

### FINAL



Stand back and enjoy your new ADD Bomber™ Front Bumper.

Check and re-tighten, if needed, all mounting bolts after 100 miles and periodically thereafter.

