2018-20XX Jeep Wrangler JL

RAVAGER STUBBY REAR BUMPER INSTALLATION INSTRUCTIONS



SAFETY

Know safety, no injury. Know injury, no safety. ~Author Unknown

- READ ALL SAFETY INSTRUCTIONS BEFORE INSTALLATION
 - o FOLLOW ALL INSTRUCTIONS FOR PROPER ASSEMBLY
 - o WEAR APPROPRIATE EYE PROTECTION
 - o EXERCISE CARE WHEN LIFTING COMPONENTS
 - USE APPROPRIATE TORQUE FOR BOLTS
 - BLUE THREAD LOCKING COMPOUND IS RECOMMENDED ON ALL BOLTS
 - O CHECK TORQUE AFTER FIRST 100 MILES

California Proposition 65



Cancer and Reproductive Harm www.P65Warnings.ca.gov

DO NOT PAINT OVER THIS LABEL. REPLACE IF DAMAGED OR LOST


DKB150 00



Suggested Torque Values For Steel Grade 5 Standard Bolts				
BOLT DIAMETER	THREADS PER INCH	TORQUE		
(INCH)		(POUND - FEET)		
1/4	20	7		
5/16	18	14		
3/8	16	25		
7/16	14	40		
1/2	13	60		
9/16	12	88		
5/8	11	120		
3/4	10	200		
7/8	9	302		
1	8	466		

Suggested Torque Values For Steel Grade 8.8 Metric Bolts				
BOLT DIAMETER	THREAD PITCH	TORQUE		
(mm)	(mm)	(POUND-FEET)		
6	1.0	7		
8	1.25	16		
10	1.5	32		
12	1.75	55		
14	2.0	88		
16	2.0	140		
18	2.5	195		
20	2.5	275		
22	2.5	375		
24	3.0	475		

1. Parts List





ITEM NO.	QTY.	PART NUMBER	DESCRIPTION
1	1	307-07-0008	12V COOL WHITE LED 120DEG BLK
2	4	316-01-0005	1.25" PLUG BT- FLUSH LDPE BLACK
3	2	443-01-0086	LICENSE PLATE MOUNTING KIT
4	1	601-56-3731	WELDNUT TAB
5	1	601-56-3744	3048MM LENGTH FOAM ROLL
6	1	601-56-4400	LICENSE PLATE BRACKET
7	2	601-56-4434	MIDDLE ACCENT PLATE
8	2	601-56-4438	STUBBY SIDE ACCENT PLATE
9	1	60K-56-0151	HARDWARE KIT # 151
10	1	60P-56-0746	JP JL STUBBY REAR BUMPER

REMOVE CONTENTS FROM BOX AND VERIFY ALL PARTS ARE PRESENT. If there are any questions, call 1-855-HHTOUGH or email HHORDERS@hammerheadarmor.com

2. TOOL LIST

- 1. 18mm socket
- 2. 15mm socket
- 3. 8mm socket
- 4. 3/4" socket
- 5. 21mm socket
- 6. 13mm wrench
- 7. 7/16" socket
- 8. 10mm wrench
- 9. T40 socket

3. REMOVAL OF OE REAR BUMPER



1. Remove the three screws in the plastic covers on both back sides of the rear bumper with an 8mm socket. Remove the plastic covers.





2. Remove the 4 bolts attaching the side reinforcement with a 15mm socket. Remove the plate from both sides.





3. Remove the 2 bolts on each side that attach the bumper. Use a 15mm socket.







4. Unplug the license plate lights and sensors (if applicable). Remove the OE rear bumper.



5. Remove the brackets and the OE tow hook from the frame. There are four bolts on the left side. Use an 18mm socket to remove them. There are two bolts on the right side. Use a 21mm socket to remove them.









4. PREPPING THE BUMPER


1. Start by placing the provided foam on the accent pieces as shown (MAKE SURE NOT TO PUT ON THE WRONG SIDE)



2. Install the accent plates on the bumper with the provided 12 black ¼" carriage head bolts and ¼" nylock nuts. Use the 7/16" socket to tighten nuts.



- 3. Install the provided led light on the license plate bracket with a 10mm wrench as shown with the red arrow.
- 4. Install the license plate bracket with two black 8mm bolts, washers, and nylock nuts using a torx 40 and a 13mm wrench as shown by the orange arrows.







5. Install lights in bumper according to their directions

5. INSTALLATION OF HAMMERHEAD BUMPER

- 6. Place provided weldnut tab in the right frame.
- 7. Place Hammerhead bumper on the frame and install the 4 OE bolts in the left side with an 18mm socket. Install the 2 OE bolts in the right side with a 21mm socket.



8. Install the provided two ½" bolts, two ½" washers, and two ½" lock washers in the bottom of the right side frame. Tighten with 3/4 " socket



9. Align bumper and torque all bolts to spec.





CONGRATULATIONS!

Your hammerhead rear bumper installation is now complete. Thank you for your purchase.