



INSTALLATION MANUAL
PREMIUM REAR BUMPER
PRODUCT NUMBER: Y5751
APPLICATION: 2022 FORD BRONCO RAPTOR



IMPORTANT SAFETY GUIDE | Your safety and the safety of others is very important.

In order to help you make informed decisions about safety, we have provided the following warnings, safety precautions, installation instructions, and other important information to alert you to potential hazards that could hurt you or others.

Please do a job safety analysis before each task to identify potential hazards for your situation and remove/protect against them. Use own good judgment and take your time.

Check packaged materials immediately upon arrival to ensure that all listed parts are included and undamaged.

Read and understand all warnings, safety precautions, and instructions before installing this product.

SENSORS FIELD OF VIEW MAY BE ALTERED WITH USE OF THE REPLACEMENT BUMPER.

WARNINGS

- Failure to observe the following warnings and instructions provided in this manual could lead to severe injury and/or death.
- For professional installation only. Careless installation and/or operation can result in serious injury, death, and/or equipment damage. All liability for installation and use rests with the user or consumer.
- Fab Fours, Inc. only approves installing this product according to these written instructions with the hardware provided. Failure to install according to these instructions will invalidate the warranty. This includes, but is not limited to, using alternative installation methods, hardware, or materials.
- This product is for off road use only.

SAFETY PRECAUTIONS

- Always remove jewelry and wear eye protection.
- Always use extreme caution when jacking up a vehicle for work. Set emergency brake and use tire blocks. Locate and use the vehicle manufacturers designated lifting points. Use jack stands.
- Always use appropriate and adequate care in lifting components into place.
- Always ensure components will remain secure during installation and operation.
- Always wear safety glasses when installing this kit. A drilling operation will cause flying metal chips. Flying chips can cause serious eye injury.
- Always use extreme caution when drilling a vehicle. Always disconnect power before welding. Thoroughly inspect the area to be drilled (on both sides of material when possible) prior to drilling, and relocate any objects that may be damaged.
- Always use extreme caution when welding a vehicle. Thoroughly inspect the area to be welded (on both sides of material when possible) prior to welding, and relocate any objects that may be a fire hazard. When welding in a cab, make sure the interior surfaces are covered (e.g., welding blanket) and a fire extinguisher is at hand.
- Always use extreme caution when cutting and trimming during fitting.
- Always tighten all nuts and bolts securely per installation instructions.
- Always route electrical cables carefully. Avoid moving parts, components that become hot, and rough or sharp edges.
- Always insulate and protect all exposed wiring and electrical terminals.
- Perform regular inspections and maintenance on mounts and hardware.

TABLE OF CONTENTS

- 2 SAFETY / DISCLAIMER
- 3 TABLE OF CONTENTS
- 4 A MESSAGE FROM THE OWNER
- 5 GETTING STARTED
- 6 PROVIDED MATERIAL
- 8 INSTALLATION
- 13 CONTACT

A MESSAGE FROM THE OWNER



Fab Fours' was born out of a passion for customizing vehicles and a love of the outdoors. Our engineering team uses the latest 3D design software to turn new product ideas into reality. In our factory, designs come to life with the combination of cutting edge technology for metal cutting and forming and an American workforce that puts its' heart and pride into every product.

From design and manufacturing, to quality and delivery, Fab Fours' mission is to be the market leader for steel truck and jeep accessories. We make sure a quality product is delivered on time, more than expected, better than expected to our customers.

Enjoy your new Fab Fours product. Welcome to the family!

Greg Higgs


FOUNDER, FAB FOURS

GETTING STARTED

Before you begin the installation process of your new Fab Fours product, we suggest laying out all materials and parts on a pad or protective surface.

Failure to fully account for all components before beginning installation may leave vehicle immobile until part is acquired. Refer to the next pages as an inventory check.

PROVIDED MATERIALS



22949- BUMPER SHELL

61632 -
EPOXY QTY:2

50300-HW -
SENSOR PLUG
HARDWARE

TOOLS REQUIRED

- 13MM SOCKET WRENCH
- 15MM SOCKET WRENCH
- 18MM SOCKET WRENCH
- 5/8" SOCKET WRENCH
- 11/16" COMBINATION WRENCH
- BODY PANEL PRY TOOL

ASSISTANCE

We recommend two people perform the installation as items are heavy and may need to be held in place while installing.

ORGANIZATION

Disassemble the vehicle where you can catalog and store everything. We suggest labeling and bagging all the OEM bolts when removing from the vehicle. Failure to keep track of parts could lead to an inability to properly reinstall components.

HARDWARE KIT | 50300-HW

FAB FOURS IDENTIFICATION	COMPONENT DESCRIPTION	QTY
50300	7/16"-14 X 1.25", HEX HEAD CAP SCREW, GRADE 8, YELLOW-ZINC	2
50300	7/16", LOCK WASHER, GRADE 8, YELLOW-ZINC	2
50300	7/16", USS FLAT WASHER, YELLOW-ZINC	4
50300	7/16"-14, HEX NUT, GRADE 8, YELLOW-ZINC	2
50300	1/2" LICENSE PLATE NUT	4
50300	ROUND PLASTIC PLUG	4
50300	1 3/8", RUBBER GROMMET	4

-
1. Unplug the wiring harness located on the driver side and passenger side of the vehicle between the frame and the bumper. (Figure 1)



Figure 1

2. From underneath the bumper, use an 18mm socket or wrench to remove the 4x (2 on each side) bolts holding the bumper to the lower frame.

If your Bronco is equipped with tow hooks remove them at this time and set them aside for later use. Use a 13mm socket or wrench to remove the 2x (1 on each side) bolts holding the bumper to the frame rails and remove the bumper from the vehicle. (Figure 2)








Figure 2

3. If vehicle is equipped with sensor; carefully remove the sensors from their housings by gently pulling the housing clips away from the sensor and pushing the sensor out. Remove the housings from the OEM bumper by compressing the clips on the inside and pushing the housing out of the bumper.

NOTE: Both the sensors and the housings are delicate and should be handled with care. Mark the location of every sensor and its respective housing for installation into the new bumper. (Figure 3-6)




-
4. Install the sensor housings into their respective locations in the bumper and use the provided epoxy packets to hold them in place. (Figure 7)




5. Install the sensors into their respective housings by carefully pushing them into the housings until the clips engage.


6. Install the license plate light into the new bumper using the provided epoxy to secure it from the inside and plug it back into the wiring harness removed earlier (Figure 8)



7. With assistance, hold the bumper up to the frame and reinstall the OEM hardware removed earlier from the bottom of the frame rails. (Figure 9)



8. Install the provided 7/16" bolts, flat washers, lock washers, and nuts into the vertical mount in the bumper. (Figure 10)



9. Using an 18mm socket wrench, tighten the previously installed OEM bolt in the bottom of the frame.

10. Using a 5/8" socket and 11/16" combination wrench, tighten the previously installed 7/16" hardware.

-
11. Reconnect the sensor harness to the vehicle by reversing the method used to remove it previously. (Figure 11 & 12)



INSTALLATION COMPLETE

CONTACT INFORMATION

**FAB FOURS INC.
2213 INDUSTRIAL PARK ROAD
LANCASTER, SC 29720**

**PHONE: (866) 385-1905
FAX: 970-385-1914
EMAIL: SUPPORT@FABFOURS.COM
FABFOURS.COM**

